

FB2100/FB2200 Flow Computer HMI Module Field Replacement Guide



For Part Numbers (Kits):

- 399379-01-0
- 621627011-KIT
- 399380-01-0
- 621627020-KIT

Device Safety Considerations

- **Reading these Instructions**

Before operating the device, read these instructions carefully and understand their safety implications. In some situations, improperly using this device may result in damage or injury. Keep this manual in a convenient location for future reference. Note that these instructions may not cover all details or variations in equipment or cover every possible situation regarding installation, operation, or maintenance. Should problems arise that are not covered sufficiently in the text, immediately contact Customer Support for further information.

- **Protecting Operating Processes**

A failure of this device – for whatever reason -- may leave an operating process without appropriate protection and could result in possible damage to property or injury to persons. To protect against this, you should review the need for additional backup equipment or provide alternate means of protection (such as alarm devices, output limiting, fail-safe valves, relief valves, emergency shutoffs, emergency switches, etc.). Contact Remote Automation Solutions for additional information.

- **Returning Equipment**

If you need to return any equipment to Remote Automation Solutions, it is your responsibility to ensure that the equipment has been cleaned to safe levels, as defined and/or determined by applicable federal, state and/or local law regulations or codes. You also agree to indemnify Remote Automation Solutions and hold Remote Automation Solutions harmless from any liability or damage which Remote Automation Solutions may incur or suffer due to your failure to ensure device cleanliness.

- **Grounding Equipment**

Ground metal enclosures and exposed metal parts of electrical instruments in accordance with OSHA rules and regulations as specified in *Design Safety Standards for Electrical Systems*, 29 CFR, Part 1910, Subpart S, dated: April 16, 1981 (OSHA rulings are in agreement with the National Electrical Code). You must also ground mechanical or pneumatic instruments that include electrically operated devices such as lights, switches, relays, alarms, or chart drives.

Important: Complying with the codes and regulations of authorities having jurisdiction is essential to ensuring personnel safety. The guidelines and recommendations in this manual are intended to meet or exceed applicable codes and regulations. If differences occur between this manual and the codes and regulations of authorities having jurisdiction, those codes and regulations must take precedence.

- **Protecting from Electrostatic Discharge (ESD)**

This device contains sensitive electronic components which be damaged by exposure to an ESD voltage. Depending on the magnitude and duration of the ESD, it can result in erratic operation or complete failure of the equipment. Ensure that you correctly care for and handle ESD-sensitive components.

System Training

A well-trained workforce is critical to the success of your operation. Knowing how to correctly install, configure, program, calibrate, and trouble-shoot your Emerson equipment provides your engineers and technicians with the skills and confidence to optimize your investment. Remote Automation Solutions offers a variety of ways for your personnel to acquire essential system expertise. Our full-time professional instructors can conduct classroom training at several of our corporate offices, at your site, or even at your regional Emerson office. You can also receive the same quality training via our live, interactive Emerson Virtual Classroom and save on travel costs. For our complete schedule and further information, contact the Remote Automation Solutions Training Department at 800-338-8158 or email us at education@emerson.com.

Ethernet Connectivity

This automation device is intended to be used in an Ethernet network which **does not** have public access. The inclusion of this device in a publicly accessible Ethernet-based network is **not recommended**.

Removing/Replacing the HMI Module

The flow computer includes a human machine interface (HMI) module. Depending upon the type ordered, it may include Wi-Fi capability and/or a liquid crystal display (LCD). In all cases the methods for removing/replacing are the same.

Restriction

Hazardous area approvals require that any part replaced in the field be the exact same part (“like-for-like”). Upgrading or substituting a different HMI module type for the factory-installed HMI module type violates hazardous area certification.

Refer to the table below for the correct field replacement part number.

Item	Field Replacement Kit Part Number
Mobile SCADA display assembly with LCD and Wi-Fi	399379-01-0
Mobile SCADA display assembly with LCD, but without Wi-Fi	621627011-KIT
Mobile SCADA display assembly without LCD but with Wi-Fi	399380-01-0
Mobile SCADA display assembly without LCD and without Wi-Fi	621627020-KIT
UL Kit File Number: E192567	

Ambient Temperature Range

May be used up to a *maximum* ambient temperature of 80°C and a *minimum* ambient temperature of –40°C; refer to the data plate attached to the device for ambient temperature.

Note

IECEX/ATEX Ambient Temperature Range: –25 °C to 55 °C

Required Tools

- #1 Phillips-head screwdriver
- #2 Phillips-head screwdriver
- 3/32-inch flat head screwdriver (for 3.81 mm pitch terminal block connections and disconnecting the internal connector to the sensor)
- Hexagonal torque wrenches. Ranges must include 4 to 6 in-lbs (0.5 to 0.7 N-m).

Electrical Ratings

- **Input Voltage:** 10.5 Vdc to 30 Vdc external supply (Max power at 10 watts)

DANGER

EXPLOSION HAZARD: Ensure the area in which you perform this operation is non-hazardous. Performing this operation in a hazardous area could result in an explosion.

DANGER

EXPLOSION HAZARD: Never remove end cap(s) in a hazardous location. Removing end cap(s) in a hazardous location could result in an explosion.

WARNING

EXPLOSION HAZARD - Do not disconnect equipment unless power has been removed or the area is known to be non-hazardous.

WARNING

EXPLOSION HAZARD –Substitution of any components may impair suitability for Class I, Division 2.



Important

If this equipment is used in a manner not specified by the manufacturer, the protection provided by equipment may be impaired.



Important

The HMI module includes the Wi-Fi transceiver; once you remove the HMI module; Wi-Fi communication with the flow computer ceases.

Removing/Replacing the HMI Module

UL Listed HMI Module Field Installed Accessory Kit for Use in Class I, Division 2, Groups A, B, C, and D:

- Flow Computer HMI Module Display Assembly with LCD & Wi-Fi Field Installed Accessory Kit Part No. 399379-01-0 for use with UL Listed Model Series FB2100 and FB2200.
- Flow Computer HMI Module Display Assembly with LCD & without Wi-Fi Field Installed Accessory Kit Part No. 621627011-KIT for use with UL Listed Model Series FB2100 and FB2200.
- Flow Computer HMI Module Display Assembly without LCD & with Wi-Fi Field Installed Accessory Kit Part No. 399380-01-0 for use with UL Listed Model Series FB2100 and FB2200.
- Flow Computer HMI Module Display Assembly without LCD & Wi-Fi Field Installed Accessory Kit Part No. 621627020-KIT for use with UL Listed Model Series FB2100 and FB2200.

1. Open the enclosure.

Captive Fastening Screws



2. Grasp the HMI module and remove it by gently pulling it straight out.
3. To replace the HMI module, line up the printed circuit board (PCB) with the slot on the back and gently press it back on. Tighten the four captive fastening screws with a torque value of 4 to 6 in.-lbs. (0.5 to 0.7 N m).
4. Close the enclosure.

FB2100/FB2200 Flow Computer HMI Module Field Replacement Guide

D301822X012

November 2020

For customer service and technical support,
visit www.Emerson.com/SupportNet

**Global Headquarters,
North America, and Latin America:**

Emerson Automation Solutions
Remote Automation Solutions
6005 Rogerdale Road
Houston, TX 77072 U.S.A.
T +1 281 879 2699 | F +1 281 988 4445
www.Emerson.com/RemoteAutomation

Europe:

Emerson Automation Solutions
Remote Automation Solutions
Unit 1, Waterfront Business Park
Dudley Road, Brierley Hill
Dudley DY5 1LX UK
T +44 1384 487200 | F +44 1384 487258

Middle East/Africa:

Emerson Automation Solutions
Remote Automation Solutions
Emerson FZE
P.O. Box 17033
Jebel Ali Free Zone – South 2
Dubai U.A.E.
T +971 4 8118100 | F +971 4 8865465

Asia-Pacific:

Emerson Automation Solutions
Remote Automation Solutions
1 Pandan Crescent
Singapore 128461
T +65 6777 8211 | F +65 6777 0947

© 2018-2020 Remote Automation Solutions, a business unit of Emerson Automation Solutions. All rights reserved.

This publication is for informational purposes only. While every effort has been made to ensure accuracy, this publication shall not be read to include any warranty or guarantee, express or implied, including as regards the products or services described or their use or applicability. Remote Automation Solutions (RAS) reserves the right to modify or improve the designs or specifications of its products at any time without notice. All sales are governed by RAS terms and conditions which are available upon request. RAS accepts no responsibility for proper selection, use or maintenance of any product, which remains solely with the purchaser and/or end-user.